

## FITTING R210SMS / R255SMS TO MITRE SAW STAND

- Fit your Saw Mounting Brackets to the stand but do not lock down.
- Mount your mitre saw on to the brackets, adjust brackets to line up with the fixing holes on the base of your machine. (**Fig 1a**) Also, locate it more to the rear of the brackets. (**Fig 1b**)
- Using the M6 x 40 coach bolts, large washer, spring washer and Hex Nut.

**NOTE:** Do not remove the rubber feet or use the wing nuts.

Insert the coach bolt from the underside (**Fig. 2a**) of the bracket and through the base (**Fig. 2b**) of the machine. Then put the large flat washer on to the bolt followed with the spring washer and the hex nut (**Fig. 2c**). Leave these loose until all bolts are fitted and the machine is correctly aligned.

- Lock down the mounting brackets, slide the machine to the rear of the bracket (**Fig. 2d**), then fully tighten the nuts.



**Fig. 1a**



**Fig. 1b**



**Fig. 2a**



**Fig. 2b**



**Fig. 2c**



**Fig. 2d**