



# Evolution Steel Saw

Steel Cutting Circular Saw

## Service Parts List



# Service Parts List

## Evolution Steel Saw/180v2 - 7" Circular Saw

| <i>ITEM#</i> | <i>PART#</i> | <i>DESCRIPTION</i>   | <i>ITEM#</i> | <i>PART#</i> | <i>DESCRIPTION</i>   |
|--------------|--------------|----------------------|--------------|--------------|----------------------|
| 1            | 180V201      | Bolt M6              | 36           | 180V236      | Helix Gear           |
| 2            | 180V202      | Cover                | 38           | 180V238      | C-Ring               |
| 3            | 180V203      | Window               | 39           | 180V239      | Ball Bearing         |
| 4            | 180V204      | Dust Cover           | 40           | 180V240      | Body                 |
| 5            | 180V205      | Screw M4             | 41           | 180V241      | Stator Cover         |
| 6            | 180V206      | Side Dust Cover      | 42           | 180V242      | Ball Bearing         |
| 7            | 180V207      | Power Cord Cover     | 43           | 180V243      | Armature 110V        |
| 8            | 180V208      | Screw                | 44           | 180V244      | Bearing Washer       |
| 9            | 180V209      | Screw                | 46           | 180V246      | Field Coil 110V      |
| 10           | 180V210      | Power Cord           | 47           | 180V247      | Ball Bearing         |
| 12           | 180V212      | Handle Right         | 48           | 180V248      | Spring Washer        |
| 13           | 180V213      | Power Cord Clamp     | 49           | 180V249      | Motor Housing        |
| 14           | 180V214      | Screw                | 50           | 180V250      | Hex Set Screw        |
| 15           | 180V215      | Capacitor            | 51           | 180V251      | Spring Lock Assembly |
| 16           | 180V216      | Choke                | 52           | 180V252      | Tapper Screw         |
| 17           | 180V217      | Overload Switch 110V | 53           | 180V253      | Lead Assembly        |
| 18           | 180V218      | Cord Guard           | 54           | 180V254      | Screw                |
| 19           | 180V219      | Switch               | 55           | 180V255      | Brush Holder         |
| 20           | 180V220      | Handle Left          | 56           | 180V256      | Brush Assembly       |
| 21           | 180V221      | Screw                | 57           | 180V257      | Brush Cap            |
| 22           | 180V222      | Hex Set Screw        | 58           | 180V258      | Blade Guard          |
| 23           | 180V223      | Spring Washer        | 60           | 180V260      | Screw                |
| 24           | 180V224      | Washer               | 61           | 180V261      | Bracket Stop         |
| 25           | 180V225      | Flange Top           | 62           | 180V262      | Base                 |
| 27           | 180V227      | Flange Bottom        | 63           | 180V263      | Spring Pin           |
| 28           | 180V228      | Screw                | 64           | 180V264      | Lever                |
| 29           | 180V229      | Bearing Cover        | 65           | 180V265      | E-Ring               |
| 30           | 180V230      | Spindle              | 66           | 180V266      | Screw                |
| 31           | 180V231      | Key                  | 67           | 180V267      | Screw                |
| 32           | 180V232      | Ball Bearing         | 68           | 180V268      | Safety Goggles       |
| 33           | 180V233      | Screw                | 69           | 180V269      | Ear Plugs            |
| 34           | 180V234      | Bearing Retainer     | 70           | 180V270      | Hex Wrench           |
| 35           | 180V235      | Collar               | 72           | 180V272      | Carry Case           |

**Call for Pricing and Part Availability - Toll Free: 866-EVO-TOOL**



# Service Parts List

## Evolution 180v2 - 7" Circular Saw

| <i>ITEM#</i> | <i>PART#</i> | <i>DESCRIPTION</i> |
|--------------|--------------|--------------------|
| 73           | 180V273      | Fence Guide        |
| 74           | 180V274      | Side Handle        |
| 75           | 180V275      | Spring             |
| 98           | 180V298      | Manual             |

**Call for Pricing and Part Availability - Toll Free: 866-EVO-TOOL**