




No.	Description	Part Code	Qty	No.	Description	Part Code	Qty	No.	Description	Part Code	Qty
1	Blade housing 185	027-0101	1	70	Cable Clamp	027-0189	1	 evolutionpowertools.com			
2	Blade Guard 185	027-0102	1	72	E clip 9mm	F-ECLIP-9-100-ST-BO	2				
3	Motor housing Large	027-0103	1	73	Lever Hex Block	027-0192	2				
4	End Cap (Orange)	027-0104	1	74	Washer M6	F-W-M6-ST-BO	5				
5	Main handle- LHS Lock Off (Orange)	027-0105	1	75	Pan Head Screw Allen M6X20	F-SBHS-M6-20-ST-BO	1				
6	Main handle- RHS (Orange)	027-0106	1	76	Hex Nut Half M6	F-NSH-M6-ST-BO	1				
7	Front Handle-LHS softgrip (Orange)	027-0107	1	78	Socket head cap screw M6X12	F-SHCS-M6-12-ST-BO	2				
8	Front Handle-RHS softgrip (Orange)	027-0108	1	80	Parallel Guide Thumb screw (Orange)	027-0199	1				
9	Track Base	027-0109	1	81	Grub Screw M6X16	F-SSCCP-M6-16-ST-BO	3				
10	Front bevel mount VP	027-0110	1	85	Dust Hose Connector UK/EU	027-0220	1				
11	Rear bevel mount VP	027-0111	1	86	Terminal Block (2)	027-0244	1				
12	Bevel pivot plate (Cast Track 185)	027-0112	1	87	Rubber Bearing Sleeve	027-0223	1				
14	Arbour Lock Plate	027-0114	1	88	Wave Washer M6	F-WW-M6-ST-BO	2				
15	Fan baffle	027-0115	1	91	Depth Lock Lever-Track (Orange)	027-0235	1				
16	LED lens	027-0116	1	92	Rear Bevel Wing Knob- Track (Orange)	027-0237	1				
17	Depth Gauge- Cast Track (mm)	027-0117	1	94	Washer M4	F-W-M4-ST-BO	5				
18	Dust Port Adaptor (185)	027-0118	1	95	Rear Bevel Indicator (Orange)	027-0239	1				
19	Blade Guard bumper	027-0119	1	96	Rear bevel indicator screw	F-SPHPZ-M4-10-ST-BO	1				
20	Blade guard lever (Orange)	027-0120	1	98	Thumb Screw Spring	027-0243	1				
21	Adjustment lever (Orange)	027-0121	1	200	Armature Assembly 1600W (UK 110V)	027-0051	1				
22	Cam adjustment knob (Orange)	027-0122	2	201	Gearbox Assembly	027-0060	1				
24	Gearbox Housing	027-0124	1								
27	Armature 1600W (UK 110V)	027-0131	1								
28	Stator 1600W (UK 110V)	027-0135	1								
29	Switch Lock off (Orange)	027-0138	1								
30	Capacitor (UK 110V)	027-0140	1								
31	Cable UK 110V (2x1.5mm ² Rubber) 4m	027-0167	1								
32	Cable Strain (Large)	027-0152	1								
33	LED Transformer (100-120V)	027-0151	1								
34	Flanged Blade Bolt	027-0158	1								
36	Outer Flange (Machined A3)	027-0154	1								
37	Inner Flange (20mm)	027-0155	1								
38	Guard retention clip	027-0157	1								
39	Screw ST 5X25	F-TFPX-5-25-ST-BO	1								
40	Pan Head Screw M5x12	F-SPHPZ-M5-12-ST-BO	4								
41	Guard Spring	027-0160	1								
42	Bearing 6001 (C&U)	F-B-6001-2Z	1								
43	Gearbox shaft	027-0162	1								
44	Woodruf Key	027-0163	1								
45	Circlip Internal 25mm	F-CCINT-25-120-ST-BO	1								
46	Gear	027-0165	1								
47	Needle Bearing	027-0166	1								
48	Roll pin 6x40mm	F-SDH-600-40-ST-BO	1								
49	Pan Head Screw M6x18	F-SPHPZ-M6-18-ST-BO	1								
50	Coach bolt M6X21	F-CB-M6-21-ST-BO	2								
51	Countersunk Screw M4x8	F-SCHPZ-M4-8-ST-BO	2								
52	Arbour lock Spring	027-0171	1								
53	Pan Head Screw M5x50	F-SPHPZ-M5-50-ST-BO	2								
54	Screw ST 4X10	F-TFPX-4-10-ST-BO	3								
56	Brush holder cap	027-0175	2								
57	Carbon brush	027-0176	2								
58	Brush holder	027-0178	2								
59	Screw ST 4X16	F-TFPX-4-16-ST-BO	12								
60	Terminal Block (4)	027-0177	1								
61	LED unit	027-0180	1								
62	Screw ST 4X8	F-TFPX-4-8-ST-BO	1								
63	Screw ST 4X60	F-TFPX-4-60-ST-BO	2								
64	Bearing 608 (C&U)	F-B-608-2Z	1								
65	Bearing 6000 (C&U)	F-B-6000-2Z	1								
66	Parallel guide	027-0185	1								
67	Hex key M6 (6mm)	F-HEXKEY-M6-ST-BO	1								
68	Pan Head Screw M5x30	F-SPHPZ-M5-30-ST-BO	1								
69	Circlip External 16mm	F-CCEXT-16-100-ST-BO	1								

Service Parts List	027-0002A.01 - V3.9 Rev 2.05	110V UK
185mm Multi-Material Cutting Circular Saw		