




No.	Description	Part Code	Qty	No.	Description	Part Code	Qty	No.	Description	Part Code	Qty
1	Blade housing 185	027-0101	1	80	Parallel Guide Thumb screw (Orange)	027-0199	1	 evolutionpowertools.com Service Parts List 027-0002C.01 - V3.9 Rev 2.05 185mm Multi-Material Cutting Circular Saw 110V UK			
2	Blade Guard 185	027-0102	1	81	Socket head cap screw M5X10	F-SHCS-M5-10-ST-BO	1				
3	Motor housing Large	027-0103	1	85	Dust Hose Connector UK/EU	027-0220	1				
4	End Cap (Orange)	027-0104	1	87	Rubber Bearing Sleeve	027-0223	1				
5	Main handle- LHS Lock Off (Orange)	027-0105	1	89	Spring	027-0159	1				
6	Main handle- RHS (Orange)	027-0106	1	90	60° 185- Adjustable marker/gauge (mm) (Orange)	027-0226	1				
7	Front Handle - LHS	026-0107	1	93	Socket head cap screw M4X8	F-SHCS-M4-8-ST-BO	2				
8	Front Handle - RHS	026-0108	1	95	Washer M4	F-W-M4-ST-BO	2				
9	60° Cast Base 185	027-0225	1	97	Plastic Washer 8mm	027-0242	2				
12	Bevel pivot plate (60° Cast Base 185)	027-0228	1	200	Armature Assembly 1600W (UK/EU/AUS 230V)	027-0051	1				
14	Arbour Lock Plate	027-0114	1	201	Gearbox Assembly	027-0060	1				
15	Fan baffle	027-0115	1	205	60° Cast Base Assembly	027-0071	1				
16	LED Blanking plate	027-0127	1								
17	Depth Gauge- 60° Cast Base 185 (mm)	027-0230	1								
18	Dust Port Adaptor (185)	027-0118	1								
19	Blade Guard bumper	027-0119	1								
20	Blade guard lever (Orange)	027-0120	1								
21	Adjustment lever (Orange)	027-0121	2								
27	Armature 1600W (UK 110V)	027-0131	1								
28	Stator 1600W (UK 110V)	027-0135	1								
29	Switch Lock off (Orange)	027-0138	1								
30	Capacitor (UK 110V)	027-0140	1								
31	Cable UK 110V (2x1.5mm² Rubber) 3m	027-0144	1								
32	Cable Strain (Large)	027-0152	1								
34	Flanged Blade Bolt	027-0158	1								
36	Outer Flange (Pressed Steel)	027-0153	1								
37	Inner Flange (20mm)	027-0155	1								
38	Guard retention clip	027-0157	1								
39	Screw ST 5X25	F-TFPX-5-25-ST-BO	1								
40	Pan Head Screw M5x12	F-SPHPZ-M5-12-ST-BO	4								
41	Guard Spring	027-0160	1								
42	Bearing 6001 (C&U)	F-B-6001-2Z	1								
43	Gearbox shaft	027-0162	1								
44	Woodruf Key	027-0163	1								
45	Circlip Internal 25mm	F-CCINT-25-120-ST-BO	1								
46	Gear	027-0165	1								
47	Needle Bearing	027-0166	1								
48	Roll pin 6x40mm	F-SDH-600-40-ST-BO	1								
49	Pan Head Screw M6x18	F-SPHPZ-M6-18-ST-BO	1								
50	Coach bolt M6X21	F-CB-M6-21-ST-BO	2								
51	Countersunk Screw M4x8	F-SCHPZ-M4-8-ST-BO	2								
52	Arbour lock Spring	027-0171	1								
53	Pan Head Screw M5x50	F-SPHPZ-M5-50-ST-BO	2								
54	Screw ST 4X10	F-TFPX-4-10-ST-BO	3								
56	Brush holder cap	027-0175	2								
57	Carbon brush	027-0176	2								
58	Brush holder	027-0178	2								
59	Screw ST 4X16	F-TFPX-4-16-ST-BO	8								
60	Terminal Block (4)	027-0177	1								
62	Screw ST 4X8	F-TFPX-4-8-ST-BO	1								
63	Screw ST 4X60	F-TFPX-4-60-ST-BO	2								
64	Bearing 608 (C&U)	F-B-608-2Z	1								
65	Bearing 6000 (C&U)	F-B-6000-2Z	1								
66	Parallel guide	027-0185	1								
67	Hex key M6 (6mm)	F-HEXKEY-M6-ST-BO	1								
68	Pan Head Screw M5x30	F-SPHPZ-M5-30-ST-BO	1								
69	Circlip External 16mm	F-CCEXT-16-100-ST-BO	1								
70	Cable Clamp	027-0189	1								
72	E clip 9mm	F-ECLIP-9-100-ST-BO	2								
73	Lever Hex Block	027-0192	2								
74	Washer M6	F-W-M6-ST-BO	2								
75	Rivet 8mm	027-0179	2								
77	Detent Bearing Grub Screw	027-0196	1								