



R255 SMS

Service Parts List	V: 052-0001	230V
255mm TCT Sliding Mitre Saw		UK

No.	Description	Part Code	Qty	No.	Description	Part Code	Qty	No.	Description	Part Code	Qty
1	BASE	052-0101	1	81	CROSS HEAD SCREW M5X10	F-SPHPZ-M5-10-ST-BO	2				
2	GROMMET 10MM	052-0102	1	82	BEVEL BRACKET COVER	052-0193	2				
3	HEX KEY	052-0325	1	83	SHAFT SEAL RING	052-0194	4				
4	TABLE EXTENSION	052-0104	2	84	RUBBER STOP	052-0195	2				
5	FOOT	052-0105	4	85	LINEAR BALL BEAING	052-0196	4				
6	HEX HEAD BOLT M10X30	F-HB-M10-30-20-ST-BO	1	86	BEVEL LABEL	052-0197	1				
8	WAVE WASHER 12MM	F-WW-M12-ST-BO	2	87	NECK	052-0198	1				
9	NYLOCK NUT M10	F-NNIF-M10-ST-BO	2	88	33.9 PIN	052-0200	1				
10	FLANGED CAP SCREW M6X16	F-SFCS-M6-16-ST-BO	12	89	FLAT WASHER 8MM	F-W-M8-ST-BO	1				
11	TABLE POSITIONING HANDLE	052-0111	1	90	BEVEL LOCK LEVER	052-0202	1				
12	SPRING	052-0113	1	91	SLIDING LOCK SCREW	052-0204	1				
13	TABLE LOCKING KNOB	052-0114	1	92	BEARING SPACER	052-0206	2				
14	PUSH ROD	052-0116	1	93	SOCKET HEAD CAP TAPPING SCREW (ST4.5X16)	052-0319	1				
15	EXTERNAL E-CLIP 6MM	F-ECLIP-6-100-ST-BO	1	94	REAR HANDLE	052-0208	1				
16	SPRING	052-0118	1	102	TORSION SPRING	052-0211	1				
17	SCREW M6X45	F-SHCS-M6-45-ST-BO	1	103	LOWER GUARD	052-0212	1				
18	NYLOCK NUT M6	F-NNIF-M6-ST-BO	1	104	GUARD ROLLER	052-0213	1				
19	TABLE	052-0121	1	105	FLAT WASHER M4 (LARGE FORM)	F-WD-M10-ST-BO	1				
20	MITRE INDICATOR	052-0122	1	106	CROSS HEAD SCREW M4X8	F-SPHPZ-M4-8-ST-BO	1				
22	GRUB SCREW M6X20	F-SSCFP-M6-20-ST-BO	2	107	BLADE GUARD RETAINING RING	052-0216	1				
23	HEX NUT M6	F-NSF-M6-ST-BO	4	109	INNER FLANGE (25.4MM)	052-0218	1				
24	CAP SCREW M6X25	F-SHCS-M6-25-ST-BO	2	110	OUTER FLANGE	052-0219	1				
25	BEVEL INDICATOR	052-0128	1	111	ARBOR BOLT	052-0220	1				
26	CONNECTING BOLT	052-0130	1	112	TAPPING SCREW (ST4.X16)	052-0320	2				
27	CAP SCREW M6X20	F-SHCS-M6-20-ST-BO	1	113	MOTOR END CAP	052-0222	1				
28	CHIP DEFLECTOR	052-0132	1	114	TAPPING SCREW 5X30	F-TFPX-5-30-ST-BO	4				
29	CROSS HEAD SCREW M6X16	F-SPHPZ-M6-16-ST-BO	2	116	PCB ASSEMBLY	052-0226	1				
30	CHANNEL GUIDE	052-0134	1	117	CONSTANT SPEED MAGNET	052-0227	1				
31	FENCE	052-0136	1	119	MOTOR HOUSING	052-0229	1				
32	ADJUSTABLE FENCE	052-0138	1	120	CARBON BRUSH HOLDER (230V)	052-0230	2				
33	WING SCREW	052-0322	2	121	CARBON BRUSH PAIR (230V)	052-0231	2				
38	TAPPING SCREW 4X16	F-TFPX-4-16-ST-BO	7	122	CARBON BRUSH CAP	052-0232	2				
39	ON/OFF SWITCH	052-0143	1	123	BEARING CAP	052-0233	1				
40	LASER SWITCH	052-0145	1	124	BEARING	052-0234	1				
41	LASER SWITCH CAP	052-0146	1	125	FIELD COIL 2000W (230V)	052-0235	1				
42	CAPACITOR (220V-240V)	052-0148	1	126	TAPPING SCREW (ST4.8X65)	052-0321	2				
43	LASER TRANSFORMER (230V)	052-0150	1	129	BEARING	052-0244	1				
44	TERMINAL BLOCK	052-0154	2	130	FAN BAFFLE	052-0245	1				
45	INDUCTOR (1) 230V	052-0309	1	131	UPPER GUARD	052-0246	1				
46	CABLE CLAMP	052-0156	1	132	TORSION SPING	052-0247	1				
47	CABLE SHEATH	052-0157	1	133	GUARD LOCK LEVER	052-0248	1				
48	INDUCTOR (2) RING INDUCTOR 230V	052-0312	1	134	CROSS HEAD SHOULDER SCREW M4X5.7	052-0250	1				
49	POWER CABLE (UK 230V)	052-0159	1	135	HEAD STOP	052-0251	1				
50	CABLE CLIP 230V	052-0165	1	136	SPINDLE LOCK	052-0252	1				
51	LOWER HANDLE	052-0167	1	137	ROLL PIN	052-0253	1				
52	UPPER HANDLE	052-0169	1	138	COMPRESSION SPRING	052-0254	1				
53	TRIGGER	052-0171	1	139	FINGER GUARD	052-0255	1				
54	CROSS HEAD SCREW M5X40	F-SPHPZ-M5-40-ST-BO	2	140	TRENCH CUT ADJUSTMENT	052-0256	1				
55	CROSS HEAD SCREW M5X16	F-SPHPZ-M5-16-ST-BO	1	141	TRENCH CUT KNOB	052-0257	2				
56	EXTERNAL CIRCLIP 16MM	F-CCEXT-16-100-ST-PO	2	142	GUARD STOP	052-0259	1				
57	HEAD PIVOT AXLE	052-0176	1	143	BEARING	F-B-606-2Z	2				
58	CROSS HEAD SHOULDER SCREW M5X8	052-0177	2	144	CROSS HEAD SCREW M6X16	F-SPHPZ-M6-16-ST-BO	1				
59	WAVE WASHER 7MM	F-WW-M7-ST-BO	1	145	CROSS HEAD SCREW M4X16	F-SPHPZ-M4-16-ST-BO	1				
60	TRENCH STOP	052-0179	1	146	CROSS HEAD SCREW M4X8	F-SPHPZ-M4-8-ST-BO	2				
67	CABLE TIDY	052-0181	2	150	SPRING	052-0316	1				
68	CABLE STRAIN	052-0183	2	152	WING SCREW	052-0322	1				
69	LOCKDOWN PIN KNOB	052-0184	1	200	GEARBOX ASSEMBLY	052-0050	1				
70	O-RING	052-0185	2	201	LINKAGE ASSEMBLY	052-0051	1				
71	EXTERNAL E-CLIP 8MM	F-ECLIP-8-070-ST-PO	2	202	LASER ASSEMBLY	052-0052	1				
72	HEAD PIVOT	052-0187	1	204	ARMATURE ASSEMBLY 2000W (230V)	052-0054	1				
73	TORSION SPRING	052-0188	1	205	SLIDE SHAFT LOCKING UNIT	052-0062	1				
74	LASER WIRE COVER	052-0189	1	206	WORK PIECE CLAMP	052-0063	1				
80	RAIL	052-0190	2								



Service Parts List

V: 052-0001

255mm TCT Sliding Mitre Saw

230V
UK