




Service Parts List

057-0007

R255PTS - Portable Table Saw

220-240V
UK

No.	Description	Part Code	Qty	No.	Description	Part Code	Qty	No.	Description	Part Code	Qty
1	PUSH TABLE	057-0101	1	89	DUST CHUTE	057-0167	1	169	SMALL LOWER BLADE GUARD (B)	057-0332	1
2	SCREW	F-SHPHZ-M4-12-ST-BO	2	90	BLADE GUARD STOP(REAR)	057-0168	1	170	SPRING	057-0333	1
3	GUIDE RAIL (A)	057-0102	1	91	BLADE GUARD STOP(FRONT)	057-0169	1	171	SMALL LOWER BLADE GUARD (A)	057-0334	1
4	SPRING	057-0103	1	93	FLAT WASHER	057-0171	6	172	SCREW	F-SHPHZ-M4-12-ST-BO	1
5	BOLT	F-SHCS-M5-12-ST-BO	6	94	LOWER BLADE GUARD PLATE	057-0172	1	174	HEX BOLT	057-0338	1
6	INSERT PLATE	057-0104	1	95	AXIAL SCREW	057-0173	2	175	SQUARE NUT	057-0339	1
7	INSERT PLATE LOCKING PLATE	057-0105	1	97	MOUNT PLATE	057-0175	1	176	LOCK NUT	057-0340	1
8	NUT NYLOCK	F-NNIF-M5-ST-BO	11	98	NYLOCK NUT	F-NNIF-M8-ST-BO	10	177	SPRING WASHER	057-0341	1
9	SCREW	F-SHCS-M6-16-ST-BO	2	99	WASHER	057-0176	3	178	BUSHING	057-0342	2
10	SPRING WASHER	F-SWA-M6-ST-BO	1	100	LOCKING PAD	057-0177	1	180	LOCK NUT	057-0343	1
11	LEFT COVER	057-0335	1	101	LOCKING SCREW	057-0178	1	181	WASHER	057-0344	1
12	HEX NUT	057-0336	2	102	BEVEL LOCKING HANDLE	057-0179	1	182	WASHER	057-0345	2
13	HEX SCREWS	057-0337	2	103	ANGLE FIX SCREW	057-0180	1	213	THUMB WHEEL	057-0256	6
14	SCREW	F-SHPHZ-M4-12-ST-BO	3	104	ANGLE INDICATOR	057-0181	1	260	MOTOR ASSEMBLY 230V UK/EU	057-0305	1
15	NUT	F-NSF-M6-ST-BO	6	105	ANGLE INDICATOR FRAME	057-0182	1	261	BLADE GUARD	057-0306	1
16	GUIDE RAIL (B)	057-0108	1	106	BRACKET - DRIVING ROD	057-0183	1	262	GEARBOX ASSEMBLY	057-0308	1
17	SCREW	F-SHPHZ-M6-35-ST-BO	8	107	BEVEL GEAR	057-0184	2	263	HOLD DOWN CLAMP	057-0350	1
18	GUIDE ROLLER	057-0109	4	108	SCREW	F-TFPX-4.2-20-ST-BO	2	264	ANGLE GAUGE	057-0351	1
19	SHOULDER SCREW	057-0110	4	112	SPLIT PIN	F-SP-3-20-ST-BO	2	265	WHEEL ASSEMBLY	057-0312	1
20	TABLE	057-0111	1	120	BEVEL GEAR PAD	057-0195	1	266	RIP FENCE ASSEMBLY	057-0352	1
21	LEFT EXTENSION TABLE LOCKING SPRING	057-0112	1	121	ELEVATION CRANK SHAFT	057-0196	1	267	HEIGHT ADJUSTMENT ASSEMBLY	057-0315	1
22	LOCKING LEVER	057-0113	1	122	SPLIT PIN	F-SP-2.5-20-ST-BO	1	268	ASSEMBLY SCREW KIT	057-0321	1
23	INDICATOR	057-0114	1	123	CABINET	057-0197	1	301	BIG FENCE	057-0346	1
24	FLAT WASHER	F-W-M4-ST-BO	9	124	CARRIAGE BOLT	057-0198	1	302	NUT	057-0347	2
25	SPRING WASHER	F-SWA-M4-ST-BO	12	125	SPACER	057-0199	1	317	HEX SCREWS	057-0348	2
26	SCREW	F-SHPHZ-M4-8-ST-BO	5	126	BLADE WRENCH (A)	057-0200	1	501	FLAT END CAP	057-0280	6
27	NUT NYLOCK	F-NNIF-M6-ST-BO	12	127	BLADE WRENCH (B)	057-0201	1	502	SPACER	057-0281	8
28	FIXING HOLDER	057-0115	1	128	POWER CORD 230V (UK)	057-0202	1	505	STAND COMPONENT	057-0284	2
29	CARRIAGE BOLT	057-0116	1	129	CABLE CLAMPS	057-0207	2	506	STAND COMPONENT	057-0285	1
30	EXTENSION TABLE LOCKING HANDLE	057-0117	1	130	SCREW	F-TFPX-4.2-16-ST-BO	13	509	STAND COMPONENT	057-0288	1
31	PLATE	057-0118	2	131	SWITCH CLAMP	057-0208	1	510	STAND COMPONENT	057-0289	1
32	CLAMPING PLATE	057-0119	2	132	CORD CLAMP PLATE	057-0209	2	513	LATCH HOOK SPRING	057-0349	1
33	LOCKING BLOCK SPRING	057-0120	2	133	SWITCHBOX	057-0210	1	517	STAND COMPONENT	057-0295	1
34	FRONT LOCKING FOR EXTENSION TABLE	057-0121	1	134	OVERLOAD SWITCH 230V (UK/EU)	057-0211	1	520	STAND COMPONENT	057-0298	1
35	REAR LOCKING FOR EXTENSION TABLE	057-0122	1	135	CONNECTING CORD	057-0215	1	525	ROUND END CAP	057-0302	2
37	FRONT RAIL	057-0314	1	136	CAPACITOR 230V (UK/EU)	057-0216	1				
40	REAR RAIL	057-0313	1	137	SWITCH HOLDER	057-0220	1				
42	RIGHT EXTENSION TABLE	057-0129	1	138	SWITCH 230V (UK/EU)	057-0221	1				
43	HEX NUT	F-NSF-M5-ST-BO	6	140	GEAR RACK	057-0225	1				
44	SCREW	F-SHPHZ-M5-20-ST-BO	1	141	WASHER	F-W-M6-ST-BO	2				
45	LOCKING PLATE	057-0130	4	142	BASE PLATE	057-0226	1				
46	FLAT WASHER	057-0131	4	143	CABLE CLAMPS	057-0227	2				
47	BOLT	F-SHCS-M5-16-ST-BO	4	144	90 ANGLE ADJUSTMENT WHEEL	057-0228	1				
48	SCREW	F-TFPX-4.2-13-ST-BO	7	145	45 ANGLE ADJUSTMENT WHEEL	057-0229	1				
50	SCREW	F-TFPX-3.5-9.5-ST-BO	4	146	CORD GUARD	057-0230	1				
51	COIL SPRING	057-0133	2	147	PUSH STICK	057-0231	1				
52	CARBON BRUSH (PR)	057-0134	2	148	RIVING KNIFE BRACKET	057-0232	1				
53	BRUSH HOLDER	057-0135	2	149	RIVING KNIFE	057-0233	1				
58	SPRING WASHER	F-SWA-M5-ST-BO	19	150	RIVING KNIFE CLAMP	057-0234	1				
68	DOUBLET NUT	057-0150	1	151	HEX SCREW	F-HFB-M6-25-ST-BZP	4				
69	C-RING	057-0151	1	152	INSERT PLATE LOCK	057-0235	1				
72	SCREW	F-SHPHZ-M5-10-ST-BO	9	153	SCREW	F-TFPX-4-8-ST-BO	1				
77	MOTOR BRACKET	057-0157	1	154	LOCK PIN	057-0236	1				
78	BLADE GUARD	057-0158	1	155	SPRING	057-0237	1				
79	INNER FLANGE	057-0159	1	156	PIN CAP	057-0238	1				
81	OUTER FLANGE	057-0160	1	159	BASE LABEL	057-0240	1				
82	BLADE BOLT	057-0161	1	160	LOGO LABEL	057-0241	1				
83	REAR ROTATE BLOCK	057-0162	1	161	BEVEL LABEL	057-0242	1				
84	CROSS-SCREW	F-SCHPZ-M5-18-ST-BO	4	162	NAMEPLATE	057-0243	1				
85	SET SCREW	057-0163	2	163	BUSH	057-0244	1				
86	REAR MOUNT PLATE	057-0164	1	164	WASHER	F-W-M6-ST-BO	2				
87	FRONT ROTATE BLOCK	057-0165	1	165	COUNTERSUNK SCREW	F-SCHPZ-M5-16-ST-BO	5				
88	FRONT MOUNT PLATE	057-0166	1	167	HEX NUT	F-NF5-M8-ST-BZP	1				

Service Parts List

057-0007

R255PTS - Portable Table Saw

220-240V
UK