

No.	Description	Part Code	Qty	No.	Description	Part Code	Qty	No.	Description	Part Code	Qty
A1	BASE	116-0101	1	B34	LOWER GUARD RIGHT	116-0140	1	E3	PAN SCREW M4 X 16	F-TFPX-M4-16-ST-BO	5
A2	REAR SUPPORT STAND	116-0102	1	B35	FLANGE INNER	116-0141	1	E4	CAP SCREW M5 X 14	F-SHCS-M5-14-ST-BO	4
A3	FENCE FIXED	116-0103	1	B36	ARBOR BOLT	116-0142	1	E5	SPRING WASHER M5	F-SWA-M5-ST-BO	4
A4	FLANGED CAP SCREW M6 X 20	F-SFCS-M6-20-ST-BO	10	B37	LOWER GUARD LEFT	116-0143	1	E6	FLAT WASHER M5	F-W-M5-ST-BO	4
A5	FOOT	116-0104	5	B38	MITRE SAW DUST PORT RIGHT	116-0144	1	E7	TABLE PIVOT ARM CAP	116-0193	1
A6	BASE EXTENSION	116-0105	2	B39	MITRE SAW DUST PORT LEFT	116-0145	1	E8	TABLE PIVOT ARM SCREW M6	116-0194	1
A7	TOP CLAMP KNOB SCREW M6	116-0106	1	B40	LOWER GUARD PIVOT SHAFT	116-0146	1	E9	NYLOC NUT M6	F-NNIF-M6-ST-BO	1
A8	PAN SCREW M5 X 8	F-SPHPZ-M5-8-ST-BO	4	B41	MITRE SAW DUST PORT RING CAP	116-0147	1	E10	TABLE PIVOT BRACKET	116-0195	1
A9	MITRE LOCK KNOB	116-0107	1	B42	LEFT HEAD FRAME COVER	116-0148	1	E11	TABLE TOP	116-0196	1
A10	MITRE LOCK PIN	116-0108	1	B43	PAN SCREW M5 X 40	F-SFPX-M5-40-ST-BO	2	E12	TABLE TOP BLANKING PLATE	116-0197	1
A11	MITRE LOCK ARM BRACKET	116-0109	1					E13	RIVING KNIFE	116-0198	1
A12	MITRE RELEASE BUTTON	116-0110	1	C1	UPPER FRONT HANDLE	116-0149	1	E14	RIVING KNIFE GUIDE BRACKET	116-0199	1
A13	MITRE POINTER	116-0111	1	C2	FLANGED PAN SCREW M5 X 30	F-SPHPZ-M5-30-ST-BO	4	E15	TABLE KERF PLATE	116-0200	1
A14	FLANGED PAN SCREW M5 X 10	F-SFPX-M5-10-ST-BO	1	C3	HANDLE WIRE CAP	116-0150	2	E16	CAP SCREW M6 X 20	F-SHCS-M6-20-ST-BO	2
A15	MITRE TABLE	116-0112	1	C4	TERMINAL CONNECTOR	116-0151	1	E26	TABLE SCALE MARKINGS METRIC (UK / EU / AUS)	116-0205	1
A16	MITRE KERF PLATE	116-0113	1	C5	PAN SCREW M4 X 8	F-TFPHS-M4-8ST-BO	2	E100	BLADE GUARD ASSEMBLY	116-0216	1
A17	CAP SCREW M6 X 16	F-SHCS-M6-16-ST-BO	3	C6	TABLE TOP PIVOT SAFETY SWITCH BUTTON BRACKET	116-0152	1				
A18	NUT M6	F-NSF-M6-ST-BO	3	C7	TABLE TOP PIVOT SAFETY SWITCH BUTTON	116-0153	1	F100	FENCE ASSEMBLY	116-0217	1
A19	MITRE LOCK PUSH ROD	116-0114	1	C8	TABLE TOP PIVOT SAFETY SWITCH BUTTON SPRING	116-0154	1				
A20	BEVEL POINTER	116-0115	1	C9	TABLE TOP PIVOT SAFETY SWITCH BUTTON SPRING CAP	116-0155	1	G100	TOP CLAMP	116-0218	1
A21	CAP SCREW M5 X 12	F-SHCS-M5-12-ST-BO	2	C10	TABLE TOP PIVOT SAFETY SWITCH	116-0156	1				
A22	BEVEL BLOCK	116-0116	1	C11	MITRE SAW ON / OFF SWITCH	116-0157	1				
A23	BEVEL LOCK LEVER	116-0117	1	C12	TABLE SAW ON / OFF SWITCH	116-0158	1				
A24	FLAT WASHER M8	F-W-M8-ST-BO	1	C13	LOWER FRONT HANDLE	116-0159	1				
A25	NYLOC NUT M10	F-NNIF-M10-ST-BO	1	C14	SCREW M4 X 16	F-TFPHS-M4-16ST-BO	4				
A26	SPRING WASHER M10	F-SWA-M10-ST-BO	1								
A27	FLAT WASHER M10	F-W-M10-ST-BO	1	D1	FLANGED PAN SCREW M5 X 30	F-SPHPZ-M5-30-ST-BO	4				
A28	BEVEL BLOCK FLIP STOP	116-0118	1	D2	PAN SCREW M4 X 16	F-TFPX-M4-16-ST-BO	2				
A29	COUNTER SINK SCREW M6 X 30	F-SCHPZ-M6-30-ST-BO	2	D3	MOTOR END CAP	116-0160	1				
				D4	CARBON BRUSH ASSEMBLY	116-0161	2				
B1	HEAD ROTATION LEVER ARM	116-0119	1	D5	MOTOR HOUSING CABLE GROMMET	116-0162	1				
B2	HEAD ROTATION LEVER KNOB	116-0120	1	D6	MOTOR HOUSING	116-0163	1				
B3	COUNTER SINK SCREW M5 X 12	F-SCHPZ-M5-12-ST-BO	3	D7	MOTOR REAR BEARING CAP	116-0164	1				
B4	LOWER BLADE GUARD LEVER BRACKET	116-0121	1	D8	ARMATURE 230V (UK / EU / AUS)	116-0165	1				
B5	LOWER BLADE GUARD SPRING	116-0122	1	D9	FIELD COIL 230V (UK / EU / AUS)	116-0167	1				
B6	LOWER BLADE GUARD LEVER	116-0123	1	D10	PAN SCREW M4 X 65	F-TFPX-M4-65-ST-BO	2				
B7	TABLE SAW DUST SHOOT	116-0124	1	D11	TABLE PIVOT RELEASE KNOB	116-0169	1				
B8	SCREW	116-0214	1	D12	MOTOR AIR BAFFLE	116-0170	1				
B9	HEAD FRAME	116-0125	1	D13	TABLE PIVOT BRACKET SCREW M8 X 12	116-0171	1				
B10	HEAD PIVOT SAFETY CATCH SPRING	116-0126	1	D14	WAVE WASHER M10	F-WW-M10-ST-BO	1				
B11	HEAD PIVOT SAFETY CATCH ROD	116-0127	1	D15	TABLE PIVOT ARM	116-0172	1				
B12	ECLIP INTERNAL 6MM	F-ECLIP-6-ST-BO	1	D16	GEARBOX HOUSING	116-0173	1				
B13	HEAD PIVOT SAFETY CATCH GUIDE BRACKET	116-0128	1	D17	TABLE PIVOT RELEASE KNOB SPRING SHROUD	116-0174	1				
B14	FLANGED PAN SCREW M4 X 10	F-SFPX-M4-10-ST-BO	2	D18	TABLE PIVOT RELEASE KNOB SPRING	116-0175	1				
B15	MOTOR PIVOT SPRING	116-0129	1	D19	TABLE PIVOT RELEASE KNOB SHAFT	116-0176	1				
B16	PAN SCREW M5 X 20	F-SPHPZ-M5-20-ST-BO	2	D20	NYLOC NUT M10	F-NNIF-M10-ST-BO	1				
B17	SWITCH WIRING COVER BRACKET	116-0130	1	D21	FLAT WASHER M10	F-W-M10-ST-BO	1				
B18	PAN SCREW M5 X 14	F-SPHPZ-M5-14-ST-BO	1	D22	CIRCLIP INTERNAL 33MM	F-CCINT-33-ST-BO	1				
B19	HEAD PIVOT SHAFT	116-0131	1	D23	COUNTERSINK SCREW M5 x 16	F-SCHPZ-M5-16-ST-BO	1				
B20	TORSION SPRING HEAD	116-0132	1	D24	MOTOR WOODRUFF KEY	116-0177	1				
B21	TORSION SPRING HEAD SHROUD	116-0133	1	D31	PAN SCREW M5 X 40	F-SPHPZ-M5-40-ST-BO	2				
B22	FLANGED PAN SCREW M5 X 30	F-SFPX-M5-30-ST-BO	1	D32	ELECTRONICS HOUSING RIGHT	116-0181	1				
B23	HEAD PIVOT RELEASE KNOB	116-0134	1	D33	POWER CABLE & PLUG 230V (UK)	116-0182	1				
B24	CAP SCREW M6 X 16	F-SHCS-M6-16-ST-BO	1	D34	PAN SCREW M4 X 16	F-TFPX-M4-16-ST-BO	4				
B25	HEAD PIVOT STOP	116-0135	1	D35	CABLE STRAIN RELIEF CLAMP	116-0186	1				
B26	F-SDH-600-30-ST-BO	F-SDH-600-30-ST-BO	1	D36	CABLE STRAIN RELIEF	116-0187	1				
B27	PAN SCREW M4 X 14	F-TFPHS-M4-14-ST-BO	4	D37	TERMINAL CONNECTOR	116-0188	2				
B28	PAN SCREW M4 X 10	F-SPHS-M4-10-ST-BO	1	D38	PCB	116-0189	1				
B29	FLAT WASHER M4	F-W-M4-ST-BO	1	D39	ELECTRONICS HOUSING LEFT	116-0190	1				
B30	SPRUNG LOWER GUARD BLADE COVER	116-0136	1	D100	ARBOR SHAFT ASSEMBLY	116-0215	1				
B31	SPRUNG LOWER GUARD BLADE COVER SPRING	116-0137	1								
B32	TORSION SPRING LOWER GUARD	116-0138	1	E1	UPPER BLADE GUARD LEFT	116-0191	1				
B33	HEAD ROTATION LEVER ARM SHAFT	116-0139	1	E2	UPPER BLADE GUARD RIGHT	116-0192	1				



Service Parts List

V1.0

R210MTS G2

UK 230V

ALL PARTS

116-0001