



R165
CCSL

| | | |
|---|------------------------------------|-------------|
| Service Parts List | 026-0003.01 - V3.8 Rev 2.04 | 230V |
| 165mm Multi-Material Cutting Circular Saw | | EU |

| No. | Description | Part Code | Qty | No. | Description | Part Code | Qty | No. | Description | Part Code | Qty |
|-----|-------------------------------------|---------------------|-----|-----|-------------|-----------|-----|-----|-------------|-----------|-----|
| 1 | Blade housing 165 | 026-0101 | 1 | | | | | | | | |
| 2 | Blade Guard 165 | 026-0102 | 1 | | | | | | | | |
| 3 | Motor Housing Small | 026-0103 | 1 | | | | | | | | |
| 4 | End Cap (Orange) | 027-0104 | 1 | | | | | | | | |
| 5 | Main handle- LHS Lock Off (Orange) | 027-0105 | 1 | | | | | | | | |
| 6 | Main handle- RHS (Orange) | 027-0106 | 1 | | | | | | | | |
| 7 | Front Handle - LHS | 026-0107 | 1 | | | | | | | | |
| 8 | Front Handle - RHS | 026-0108 | 1 | | | | | | | | |
| 14 | Arbour Lock Plate | 027-0114 | 1 | | | | | | | | |
| 15 | Fan baffle | 027-0115 | 1 | | | | | | | | |
| 18 | Dust Port Adaptor (165) | 026-0118 | 1 | | | | | | | | |
| 19 | Blade Guard bumper | 027-0119 | 1 | | | | | | | | |
| 20 | Blade guard lever (Orange) | 027-0120 | 1 | | | | | | | | |
| 21 | Adjustment lever (Orange) | 027-0121 | 2 | | | | | | | | |
| 28 | Stator 1200W (230V) | 026-0134 | 1 | | | | | | | | |
| 29 | Switch Lock off (Orange) | 027-0138 | 1 | | | | | | | | |
| 30 | Capacitor (UK/EU 230V) | 027-0139 | 1 | | | | | | | | |
| 31 | Cable EU 230V 3m | 027-0145 | 1 | | | | | | | | |
| 32 | Cable Strain (Small) | 027-0149 | 1 | | | | | | | | |
| 34 | Flanged Blade Bolt | 027-0158 | 1 | | | | | | | | |
| 36 | Outer Flange (Pressed Steel) | 027-0153 | 1 | | | | | | | | |
| 37 | Inner Flange (20mm) | 027-0155 | 1 | | | | | | | | |
| 38 | Guard retention clip | 027-0157 | 1 | | | | | | | | |
| 39 | Screw ST 5X25 | F-TFPX-5-25-ST-BO | 1 | | | | | | | | |
| 40 | Counter Sunk Screw M5x12 | F-SCHS-M5-12-ST-BO | 4 | | | | | | | | |
| 41 | Guard Spring | 027-0160 | 1 | | | | | | | | |
| 48 | Roll pin 6x40mm | F-SDH-600-40-ST-BO | 1 | | | | | | | | |
| 49 | Counter Sunk Screw M5x25 | F-SCHS-M5-25-ST-BO | 1 | | | | | | | | |
| 50 | Coach bolt (R1B) M6X14 | F-CB-M6-21-14-ST-BO | 2 | | | | | | | | |
| 51 | Pan Head Screw M3x16 | F-SPHPZ-M3-16-ST-BO | 1 | | | | | | | | |
| 52 | Arbour lock Spring | 027-0171 | 1 | | | | | | | | |
| 53 | Pan Head Screw M5x50 | F-SPHPZ-M5-50-ST-BO | 2 | | | | | | | | |
| 54 | Screw ST 4X10 | F-TFPX-4-10-ST-BO | 3 | | | | | | | | |
| 56 | Brush holder cap | 027-0175 | 2 | | | | | | | | |
| 57 | Carbon brush (Pr) | 027-0176 | 2 | | | | | | | | |
| 58 | Brush holder | 027-0178 | 2 | | | | | | | | |
| 59 | Screw ST 4X16 | F-TFPX-4-16-ST-BO | 8 | | | | | | | | |
| 60 | Terminal Block (4) | 027-0177 | 1 | | | | | | | | |
| 63 | Screw ST 4X50 | F-TFPX-4-50-ST-BO | 2 | | | | | | | | |
| 66 | Parallel guide | 027-0185 | 1 | | | | | | | | |
| 67 | Hex key M6 | F-HEXKEY-M6-ST-BO | 1 | | | | | | | | |
| 68 | Pan Head Screw M5x30 | F-SPHPZ-M5-30-ST-BO | 1 | | | | | | | | |
| 70 | Cable Clamp | 027-0189 | 1 | | | | | | | | |
| 72 | E clip 9mm | F-ECLIP-9-100-ST-BO | 2 | | | | | | | | |
| 73 | Lever Hex Block | 027-0192 | 2 | | | | | | | | |
| 74 | Washer M6 | F-W-M6-ST-BO | 2 | | | | | | | | |
| 80 | Parallel Guide Thumb screw (Orange) | 027-0199 | 1 | | | | | | | | |
| 81 | Socket head cap screw M5X10 | F-SHCS-M5-10-ST-BO | 1 | | | | | | | | |
| 85 | Dust Hose Connector UK/EU | 027-0220 | 1 | | | | | | | | |
| 87 | Rubber Bearing Sleeve | 027-0223 | 1 | | | | | | | | |
| 89 | Spring | 027-0159 | 1 | | | | | | | | |
| 201 | Gearbox Assembly | 026-0060 | 1 | | | | | | | | |
| 202 | Armature Assembly 1200W (230V) | 026-0050 | 1 | | | | | | | | |
| 208 | 165 Pressed Base Assembly | 026-0070 | 1 | | | | | | | | |



| | | |
|---|------------------------------------|-------------------|
| Service Parts List | 026-0003.01 - V3.8 Rev 2.04 | 230V EU |
| 165mm Multi-Material Cutting Circular Saw | | |