

Service Parts List	V: 005-0005
Mitre Stand Plus	

No.	Description	Part Code	Qty
1	FRAME	005-0203	1
2	HEXAGON SOCKET SCREW M8*20	F-SHCS-M8-20-ST-BO	2
3	SPRING WASHER Φ8	F-SWA-M8-ST-BO	2
4	FLAT OUTER HEXAGON M6*16	005-0206	2
7	LOWER LEG	005-0207	4
8	LOWER LEG CAP	005-0208	4
9	SPRING	005-0209	4
10	LEG BUSHING	005-0210	4
11	LEG CAP	005-0211	4
12	UPPER LEG	005-0212	4
15	CARRIAGE BOLTS M10*60	005-0213	4
16	LOCK NUT M10	F-NNIF-M10-ST-BO	8
17	UPPER LEG CAP	005-0215	4
18	REINFORCEMENT SEAT	005-0216	2
19	FLAT WASHER Φ8*16*1.2	005-0217	2
20	HAND WHEEL- TABLE	005-0218	2
23	EXTENSION TUBE	005-0219	2
24	END CAP- EXTENSION TUBE	005-0220	4
25	MITRE STAND SUPPORT BRACKET	MITSTAND800SUPBRA	2
26	LONG LOCKING SCREW	MITSTAND800KNF	4
32	CROSS HEAD SCREW M6*8	005-0221	2
34	GALVANIZED PIPE POSITIONING BLOCK	005-0222	2
35	CROSS COUNTERSUNK HEAD SCREW M5*12	F-SCHPZ-M5-12-ST-BO	4
36	LOCK NUT M5	F-NNIF-M5-ST-BO	4
37	WORKPIECE SUPPORT HANDLE	MITSTAND800BRACKHAND	2
40	FLAT WASHER Φ6*Φ16*2	005-0225	10
41	SPRING WAHSER Φ6	F-SWA-M6-ST-BO	2
42	NUT M6	F-NSF-M6-ST-BO	2
43	EXTENSION SUPPORT WIDTH	005-0228	2
44	EXTENSION SUPPORT LENGTH	005-0229	2
46	CROSS PAN HEAD SCREW M6*35	F-SPHPZ-M6-35-ST-BO	2
52	BLOCK REAR	005-0231	2
54	HALF-ANGLE BLOCK	005-0232	2
55	SQUARE BLOCK	005-0233	4
56	WORKPIECE SUPPORT HANDLE	005-0234	1
57	ST SCREW M5*16	F-TFPX-5-16-ST-BO	2
58	WHEEL SHAFT	005-0236	2
59	FLAT WASHER Φ12*Φ24*1.5	005-0235	2
60	WHEEL	005-0238	2
61	FLAT WASHER Φ10	F-W-M10-ST-BO	2
62	LEG LOCKING ASSEMBLY	005-0200	1
63	ROLLER ASSEMBLY	005-0201	1
64	HANDLE	005-0202	1
65	MOUNTING BRACKET	MITSTAND800MOUNBRPR	1
66	ASSEMBLY SCREW KIT	005-0237	1

Service Parts List | **V: 005-0005**

Mitre Stand Plus